



[WWW.VEEDUBTRANSPORTERS.CO.UK](http://WWW.VEEDUBTRANSPORTERS.CO.UK)

# (TAILGATE CURTAINS) FITTING INSTRUCTIONS



## Time Needed



~2 Minutes

## Difficulty



Easy

Hard

# Step 1

If your Transporter van has a wiper motor on the rear window, you will need to bend the rail slightly to go round it.

The images at the bottom show how to do this correctly.

All you need to do is gently bend the rail to form the shape in the images.





[WWW.VEEDUBTRANSPORTERS.CO.UK](http://WWW.VEEDUBTRANSPORTERS.CO.UK)

Send us pictures of your fitted product on Social Media!

 **veedubtransporters**

 **Vee Dub Transporters**

For any further assistance please call our Customer Services Team



**0116 409 1911**

