



WWW.VEEDUBTRANSPORTERS.CO.UK

(T5/T6 REAR DOOR SEALS) FITTING INSTRUCTIONS



Required Tools

- Rubber Mallet
- Snips

Time Needed



~20 Minutes

Difficulty



Easy

Hard

Step 1

Find where the original seal meets and start pulling it off the bodywork of the van. Remove this slowly to ensure a smooth release.



Step 2

Starting in the same place as the genuine seal work slowly and in sections, pushing the new seal into place then use your rubber mallet to ensure it's sitting in the correct position.



Step 3

Once you've made it all the way around you may have some excess seal, use your snips to cut it to length.






WWW.VEEDUBTRANSPORTERS.CO.UK

Send us pictures of your fitted product on Social Media!

 **veedubtransporters**

 **Vee Dub Transporters**

For any further assistance please call our Customer Services Team



0116 409 1911

