



WWW.VEEDUBTRANSPORTERS.CO.UK

(SIDE DOOR STEP INSERT) FITTING INSTRUCTIONS



Required Tools

- Trim Removal Tool

Time Needed



~25 Minutes

Difficulty



Easy

Hard

Step 1

Using your trim removal tool, slowly pry around the bottom of your original step insert.

Make sure to pry upwards and not away from the van.



Step 2

Now all three bottom clips are released, carefully pull the step insert up and away from the van. If you have a cab step light, take care as there is a cable that will need disconnecting.

Squeeze the clip on the back of the light to release it.



Step 3

If any genuine clips are remaining in the van. Use a trim removal tool to carefully pry them out as you will need them to fit your new step insert.



Step 4

Insert the 3 genuine clips into your new step insert in the locations shown.



Step 5

If your van doesn't have a step light, make sure to fit the plastic insert onto the step before slotting into place.

If your van does have a step light, simply clip the light back into where you removed it.



Step 6

Slide your step into place by pushing the back making sure the three rear clips reach the back.

Then make the bottom clips line up with the grommets. Push into place to secure.



Step 7

Lightly tap into position and the fitment is complete.






WWW.VEEDUBTRANSPORTERS.CO.UK

Send us pictures of your fitted product on Social Media!

 **veedubtransporters**

 **Vee Dub Transporters**

For any further assistance please call our Customer Services Team



0116 409 1911

